

HV crates and cards(Old BB set-up)




HV

- Start GUI
 - Change to the “slowc” directory
 - Run the comand “./hvs left” or “./hvs right”
 - Logbook entry [3435487](#), says to run the HV GUI on adaq2 (adev@ adaq2)
 - This will allow communication between the CODA Auto logger and the HV GUI



HV

- Most common issues:
 - Communication error with the GUI
 - Fixed by restarting the GUI.
 - A single channel on a HV card goes bad.
 - Solved by using a spare channel to continue powering the detector.
 - Requires access to hall.
 - Need to log all changes: map to cable layouts.
- Not common issue: raspberry pi malfunctions
 - Escorted access: The only time I saw this in the logbook, Bob went in the hall to fix (last April).



Apply a Momentum distribution to our target proton



Inelastic scattering Results



Inelastic scattering Results



Inelastic scattering Results

